ASSEMB LY INSTRUCTION
ITEM NO: RYS10A

PAGE 1 OF 6

PARTS AN HARDWARE

Screw(M6)*4	Body A (2)	Back A x2	A: 17PCS
	Body A (1)		B: 4PCS
Back B x2	Seat cushion x 2	Seat cushion x 2	C: 25PCS
		Back bolster x 2	D: 2PCS
Back bolster x 2	Seat cushion x 2	Back bolster x 2	E: 13PC
Back cushion A x 1	Pillow A x2	Pillow B x2	Leg: x8

Step1:
Install the arm area and cushions area
Note: Be careful with the direction of the arm area and the back bolsters

Step2:
Secure the back areas to A

ASSEMB LY INSTRUCTION
ITEM NO: RYS10A

PAGE 2 OF 6

Step3:
Install the seat cushions

Step4:
Secure the arm areas to A

Step5:
Secure arms areas to A

Step6:
Secure the arm areas to seats via screw (M6)*4 and (M6) washer

ASSEMB LY INSTRUCTION
ITEM NO: RYS10A

PAGE 3 OF 6

Step7:
Secure the back areas to seats via (M6)*4 and (M6) washer

Step8:
Secure back bolsters to A

Step9:
Secure the back areas to A

Step10:
Secure the backs areas via (M6)*4 and (M6) washer

ASSEMB LY INSTRUCTION
ITEM NO: RYS10A

PAGE 4 OF 6

Step11:
Secure the back areas to A

Step12:
Secure the back areas via (M6)*4 and (M6) washer

Step13:
Secure the back areas to A

Step14:
Secure the back areas via (M6)*4 and (M6) washer

ASSEMB LY INSTRUCTION
ITEM NO: RYS10A

PAGE 5 OF 6

Step15:
Secure the back areas to A

Step16:
Secure the back areas via (M6)*4 and (M6) washer

Step17:
Install B

Step18:
Secure the back areas to seats via (M6)*4 and (M6) washer

ASSEMB LY INSTRUCTION
ITEM NO: RYS10A

PAGE 6 OF 6

Step19:
Secure the back areas to A

Step20:
Secure the back areas to A

Step21:
Install B to Frontend

Notes: The sofa are in fixed position. The fabrics can be reversible. Please lay them out accurately on customer's needs.

TIPS:

1. Please do not open the compress package until your sofa frame is completely assembled.
2. Fluffiness cushions or pillows need to be fully puffed within 72 hours for your pleasure.
3. Please keep children away from plastic bag or any small pieces of stuff.
4. After assembly is completed, don't forget to put the back cushions and seat cushions, make them recovering better. And wait 72 hours for fully rebound.

5. Cushions should be regularly maintained for perfect use.

STEPS for compressed pack:

(1)open the carton – (2) take out the compressed pack – (3) cut from edge and take out the cushion – (4) Put the cushion on floor – (5) Pat and tidy the cushion –(6) Wait to rebound completely after 72 hours.

CAUTION:
PLEASE DO NOT OPEN COMPRESSED PLASTIC CUSHION BACK UNTIL YOUR SOFA FRAME IS COMPLETELY ASSEMBLED, OTHERWISE, IT CAN'T BE REPACKED IN ORIGINAL PACKING WAY TO RETURN.