

RETURN / DAMAGE CLAIM INSTRUCTIONS

1. **DO NOT** discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.




















4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.


| | |
|----------------------------------|--|
| Auckland / Waikato / BOP Branch: | sales@tsbliving.co.nz |
| Christchurch Branch: | customersupport@tsbliving.co.nz |
| Wellington Branch: | wellington@tsbliving.co.nz |

ASSEMBLY INSTRUCTION


MODEL : CF 9491-B (4)

| | | |
|---|---|-------|
| A |  | 1pc |
| B |  | 1pc |
| C |  C1 C2 | 4pcs |
| D |  640 x 80 x 20mm | 2pcs |
| E |  No.125 (100*46*90H) | 2pcs |
| F |  No.134 (89*71*89) | 2pcs |
| G |  800mm | 2pcs |
| H |  1137mm | 2pcs |
| I |  185mm | 4pcs |
| J |  | 8pcs |
| K |  | 14pcs |
| L |  | 2pcs |
| M |  | 4pcs |
| N |  | 24pcs |
| O |  | 1pc |
| P |  | 1pc |
| Q |  | 6pcs |
| R |  | 8pcs |
| S |  | 4pcs |


Step 1 : Attach the headboard legs (D) to headboard (A). Attach the footboard legs (E) with footboard (B) as shown.




Step 2 : Attach the JCBB Bolt (J) to the headboard and footboard.




Step 3 : Attach the side rail leg (F) to the side rail (C).



Step 4 : Attach side rail (C) to headboard (A) and footboard (B) by pushing the bracket down to fit it.



Step 5 : Attach the support legs (I) to the center rail (G) and slats (H).



Step 6 : Tighten the 4 Corner with Allen Key (P). Install the bed slats to side rail. Tighten the slats with CSK screw. The distance of the slats should be sufficient to obtain desirable bed stability.

