

RETURN / DAMAGE CLAIM INSTRUCTIONS

1. **DO NOT** discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.










Email us directly with the attached images, order number (SOXXXX) and a description of your claim.


Auckland / Waikato / BOP Branch:	sales@tsbliving.co.nz
Christchurch Branch:	customersupport@tsbliving.co.nz
Wellington Branch:	wellington@tsbliving.co.nz

Model : CF 9272-B
(46" Full)

Assembly Instruction

Step 1 : Unzip the black non-woven fabric on the back of headboard and take out all the parts out.


A		1pc
B		1pc
C		4pcs
D		2pcs
E	 Footboard Legs Plate Code: LG NO127 (60x35x40)	2pcs
F	 Side Rail Legs NO127 - 240 x 80 x 30mm	2pcs
G	 Center Rail 800mm	2pcs
H	 1/4 Slot 1397mm	2pcs
I	 Support Legs 215mm	4pcs




Attention: Zip the black non-woven fabric after take out the parts !!

BACK VIEW

Step 2 : Attach the side wing (D) to the headboard (A). Fix the footboard with legs as shown.









Step 3 : Attach the JCBB Bolt (J) to the headboard bracket and footboard bracket.




FRONT VIEW

Step 4 : Attach the side rail leg (F) to the side rail (C).




O		1pc
P		28pcs
Q		10pcs
R		18pcs
S		4pcs

Step 5 : Attach side wing (D) to side rail (C). Attach side rail (C) to footboard (B) by pushing the bracket down to fit it.



Step 6 : Attach the support legs (I) to the slats (H).



ATTENTION:
Please keep the adjuster around 5 to 8 mm
distant away from the floor.

Step 7 : Tighten the 4 Corner with Allen Key (O). Install the bed slats to side rail. Tighten the slats with CSK screw. The distance of the slats should be sufficient to obtain desirable bed stability.

