


















version1 : Left lounge & sofa






version 2: sofa





Version 3: Right lounge & Sofa

S P A R E P A R T S	 A*1 PC	 B*1 PC	 C*1 PC	 D*1 PC
	 E*2PC	 F*2PC	 G*1 PC	 H*3PCS
	 I*2PCS	 J*8PCS	 K*10PCS	 L*1 PCS
	 M*8PCS	 N*10PCS	 O*10PCS	







There are two holes at the front of the base (C) and two holes at the bottom of the backrest (A).
To properly assemble the chair, you need to connect the backrest and the base frame, and then proceed to install all four legs.




5: version 1




6:



7: version 2



8.version 3



Exchange the chaise Longue metal hardware from both side

To change the chaise longue's position (switch the side), please remember to remove the 3 metal brackets from the current side, then screw them securely onto the other side, and finally, align the direction of the brackets as it was before change.

