

Assembly Instructions

NO.	DESCRIPTION QT	
1	Top Panel	1
2	Side Panel (L)	1
3	Side Panel (R)	1
4	Back Support Panel	2
5	Bottom Panel	1
6	Plinth Panel	2
7	Back Panel	1
8	Drawer Front Panel	4
9	Drawer Side Panel	8
10	Drawer Back Panel	4
11	Drawer Bottom Panel	4


NO.	DESCRIPTION		
А	\mathbf{L}	Allen Key M4	1
В	Ø	Dowel	20
С	and	Mini Fix Bolt	14
D	E	Mini Fix Housing	14
Е		Mini Fix Cap	14
F	Ø	Handle Screw M3.5x36mm	16
G	Ø-1111111111	CSK Screw M4x50mm	32
Н	Ø_1111Þ	CSK Screw M3.5x16mm	48
I	0	Nail	24
J		350mm Drawer Slide	4 set
Κ	J	Handle	8
L	Ŷ	White Nail Leg	4





Model: CH 8001













Step 9





RETURN / DAMAGE CLAIM INSTRUCTIONS

1. **<u>DO NOT</u>** discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch:	sales@tsbliving.co.nz
Christchurch Branch:	customersupport@tsbliving.co.nz
Wellington Branch:	wellington@tsbliving.co.nz