
















ASSEMBLY INSTRUCTIONS

Thank you for your purchase. Please follow the instructions below for correct assembly.

			9		3pcs
			10		1pc
			11		1pc
1		2pcs	12		2pcs
2		2pcs	13		2pcs
3		2pcs	14		4pcs
4		2pcs	A	 Ø6*25	4pcs
5		2pcs	B	 3. 5*60	8pcs
6		8pcs	C	 3*35	6pcs
7		4pcs	D	 3*30	12pcs
8		2pcs	E	 3*25	32pcs
			F	 3*20	20pcs
			G	 3*12	18pcs


Step 1



Attach 2x part① to 2x part②, as shown in picture.

Note: Notch of part① is downward, and notch of part② is upward.

Step 2




Attach 2x part③ above part①, and 2x part④ above part②.

Note: (1) Notch of part③ is upward, and notch of part④ is downward.


(2) Middle holes are on the opposite, as pictured.

Step 3




Attach 2x part⑥ to each corner, secure with 8x screw (E) as shown. Repeat for the rest three corners. Total 8x part⑥, using total 32x screw (E).

Step 4




Attach 2x part⑤ to the bottom (the side with holes in the middle), secure each side with 2x bolts&nuts (A), total 4x (A).

Step 5



Secure 3x part⑨ with total 6x screw (C), the left one, right one, and the middle one, as shown in picture.

Step 6




Attach canopy roof part⑩ to the top, secure 4x part⑦ above canopy, and part⑧ each on the left and right side, by using total 20x screw (F), as shown.

Step 7

Attach 1x part⑫to the bottom, secure with 6x screw (D) as pictured. Place 1x part⑬ next to part⑫, securing each hinge with 3x screw (G), total 9x screw (G).


Repeat for the other side.



Step 8

Open part⑬, attach part⑭ to the seat, securing each part⑭ with 2x screw (B). Total 4x screw (B) on each seat. Repeat for the other seat.

Place the ground sheet part⑪ underneath.



RETURN / DAMAGE CLAIM INSTRUCTIONS

1. DO NOT discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo / Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: sales@tsbliving.co.nz

Christchurch Branch: customersupport@tsbliving.co.nz

Wellington Branch: wellington@tsbliving.co.nz