







ASSEMBLY INSTRUCTIONS

Thank you for your purchase. Please follow the instructions below for correct assembly.

1		1pc	4		2pcs
			5		1pc
2		1pc	A	 3*23	6pcs
			B	 3.5*25	4pcs
			C	 3.5*35	8pcs
3		2pcs	D	 3.5*45	12pcs
			E		1pc
			F		4pcs


Step 1



Attach back panel part②to side panel part③(left and right), secure with 6x screw (D).

Secure 2x window knobs, part (F), each with 1x screw (B), total 2x screw (B).


Step 2



Secure front panel part① with 6x screw (D).


Attach 2x window knobs, part (F), by using total 2x screw (B), same as step 1

Step 3



Attach 2x roofs, part④, secure with 8x screw (C).

Step 4



Attach part⑤ to the roof, secure with 6x screw (A).

Secure doorknob part (E), with 1x screw (E).

RETURN / DAMAGE CLAIM INSTRUCTIONS

1. DO NOT discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo / Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: sales@tsbliving.co.nz

Christchurch Branch: customersupport@tsbliving.co.nz

Wellington Branch: wellington@tsbliving.co.nz