



Pop up Gazebo Instruction Manual


If the product is not equipped with side wall, please skip step 6.7.




1,2 peoples stand in sides open the tent frame slowly until it is 50% open.




2.The 4 corners of the roof align with the for corners of the frame.




3. Hold up two corners of the canopy and throw the canopy over the frame.




4 Push slider up ,until it is locked.




5.Pull out the down leg pole by your foot until it is locked.



6.The side wall cloth and the side wall cloth are connected by zipper



7.Attach the side wall cloth to the frame through the glue button



8.Attach foot pins and Ropes to the four corners

Note: Need lowered the adjustable legs before the wind storm hit!