












Assembly Instructions

Model : CH 8016-D


Part List		QTY
1	Top Panel	1
2	Right Side Panel	1
3	Left Side Panel	1
4	Top Support Panel	1
5	Drawer Support Panel	4
6	Back Support Panel	1
7	Leg Front Panel	1
8	Leg Back Panel	1
9	Back Panel	2
10	Drawer Front Panel (Lock)	1
11	Drawer Front Panel	4
12	Drawer Side Panel (L)	5
13	Drawer Side Panel (R)	5
14	Drawer Back Panel	5
15	Drawer Bottom Panel	5

Hardware			QTY
A	Dowel		47
B	Mini Fix Bolt		22
C	Mini Fix Housing		22
D	CSK Screw M4x38mm		26
E	CSK Screw M3.5x12mm		62
F	14" Drawer Slide		5
G	Nail		36
H	White Nail Leg		4
I	Drawer Lock Set		1


*Please use screwdriver when assemble CSK screw.Screwdriver (not provided)




Step 1




Step 2




Step 3




Step 4



Step 5







Step 6



Step 7

This is how a mini fix works...



The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.




Step 8

This is how a mini fix works...


The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.



Step 9




Step 10



Step 11


Step 11.1




This is how a mini fix works...

The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.

Step 11.2




Step 12.1




This is how a mini fix works...


The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.




Step 12.2




Step 13.1




Step 13.2



Step 14



Step 15




Anti -
Tipping

(A)



CSK Screw
M3.5x16mm
1PC

(B)



CSK Screw
M4x50mm
1PC



(C)









L BRACKET
2PCS





CABLE TIE
1PC



BACK VIEW



WALL



WALL

RETURN / DAMAGE CLAIM INSTRUCTIONS

1. DO NOT discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: sales@tsbliving.co.nz

Christchurch Branch: customersupport@tsbliving.co.nz

Wellington Branch: wellington@tsbliving.co.nz