



















Assembly Instructions


Model : MPC 8052

Part List		QTY
1	Top Panel	1
2	Left Side Panel	1
3	Right Side Panel	1
4	Center Left Panel	1
5	Center Right Panel	1
6	Shelf Panel	3
7	Bottom Panel	1
8	Door Panel (L)	1
9	Door Panel (Center Left)	1
10	Door Panel (Center Right)	1
11	Back Panel	2
12	Legs	2


Hardware List			QTY
A		Allen Key M4	1
B		Plastic Dowel	20
C		JCBC W Screw M6x40	4
D		Mini Fix Bolt	20
E		Mini Fix Housing	20
F		Mini Fix Cap	20
G		CSK Screw M3.5x16mm	44
H		Panhead M3.5x16mm (Black)	8
I		Panhead M3.5x25mm (Black)	7
J		H Profil	1
K		Shelf Metal Support	12
L		L Bracket	4
M		2/8 Hinges	2
N		7/8 Hinges	4
O		White Nail	6
P		Handle C/B 195mm	2
Q		Handle C/B 485mm	1



Step 1




Step 2




Step 3

This is how a mini fix works...




The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.




*Attach Minifix Cap as shown.

Step 4

This is how a mini fix works...




The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.




*Attach Minifix Cap as shown.


Step 5




Step 6




Step 7




Step 8




Step 9





Step 10



This is how a mini fix works...




The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.




*Attach Minifix Cap as shown.


Step 11




Step 12




Step 13




Step 14



Step 15



Step 16




Anti -
Tipping

(A)



CSK Screw
M3.5x16mm
1PC

(B)



CSK Screw
M4x50mm
1PC

(C)





L BRACKET
2PCS


(D)




CABLE TIE
1PC









BACK VIEW



WALL



WALL



RETURN / DAMAGE CLAIM INSTRUCTIONS

1.DO NOT discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2.Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3.Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch:	sales@tsbliving.co.nz
Christchurch Branch:	customersupport@tsbliving.co.nz
Wellington Branch:	wellington@tsbliving.co.nz

www.tsbliving.co.nz