























ASSEMBLY INSTRUCTIONS

Thank you for your purchase. Please follow the instructions below for correct assembly.


1		1PC	7		1PC
2		1PC	8		1PC
3		1PC	9		2PCS
4		1PC	10		1PC
5		1PC	11		1PC
6		1PC	12		1PC
			13		2PCS
			A		3.5*40 8PCS
			B		3.5*35 8PCS
			C		3.0*30 4PCS
			D		3.0*20 4PCS
			E		3.0*16 6PCS
			F		3.0*14 6PCS
					1PC
					1PC

Step 1




Attach front panel part①, part②to left side panel part③, secure with 4x screw (A).

Step 2



Secure right side panel part④ with 4x screw (A).


Step 3



Secure back panel part⑤ and part⑥, by using 8x screw(B).


Attach connecting part to back panel part⑤and part⑥, secure with 2x screw(F).

Step 4




Put in 2x part⑨ from top as pictured.

Step 5




Put in part⑩ first, then attach ramp part⑧ to part⑨ (the left one), secure with 2x screw (E).

Step 6




Put in part⑦ as shown.

Step 7




Attach roof part⑪, secure with 4x screw (F) at back.

Step 8




Open roof, attach one end of hinge to the roof and the other end to the right side panel, secure with 4x screw(E) as pictured.

Step 9



Connect part 12 and 2x part 13 together, secure with 4x screw(D).

Step 10



Open the left door of front upper panel, attach the part finished in step 9 to the left door, secure from inside with 4x screw(C) as pictured.

RETURN / DAMAGE CLAIM INSTRUCTIONS

1. **DO NOT** discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: sales@tsbliving.co.nz

Christchurch Branch: customersupport@tsbliving.co.nz

Wellington Branch: wellington@tsbliving.co.nz