




Hardware










Tools Required

We spower tools can strip threads if over tightened.




Components

Make sure there is no shortage or defect of the included parts and/or screws. If you find a shortage or defect, please contact the customer service for replacement.



Components

If you cannot find the parts you need of this product, please inform the customer service of your retailer.




X
2x




Y
2x




Z
2x



A1
2x




B1
2x




C1
1x

Assembly Instructions


1.




2.



3.




4.




Assembly Instructions


5.




6.



7.




8.




Assembly Instructions


9.




10.



11.




12.




Assembly Instructions


13.



14.



15.



16.

