


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT


Tools Required For Assembly:

Allen Wrench




(Included)

Wrench








(Included)



2 PERSONS RECOMMENDED

Parts List

	#1 x 1pc Headboard
	#2 x 1pc Footboard
	#3 x 2pcs Side Rail
	#4 x 2pcs Wings
	#5 x 2pcs (L & R) HB Leg
	#6 x 2pcs FB Leg
	#7 x 39pcs Slat
	#8 x 2pcs Support Rail
	#9 x 6pcs Support leg
	#10 x 1pc HB Leg Support


Hardware List

	#A x 1pc Allen Wrench
	#B x 16pcs Bolt Ø5/16"X1-1/2"
	#C x 24pcs Bolt Ø5/16"X2"
	#D x 2pcs Bolt Ø5/16"X4"
	#E x 32pcs Flat Washer Ø5/16"X19MM
	#F x 10pcs Flat Washer Ø5/16"X22MM
	#G x 42pcs Lock Washer
	#H x 16pcs Nut
	#I x 1pc Wrench
	#J x 26pcs End Cap
	#K x 26pcs Center Plastic Connector

STEP 1

1) Remove headboard legs (#5) from the back compartment of the headboard (#1).

#Cx 4pcs
#Fx 4pcs
#Gx 4pcs



2) Prepare 4 bolts assembly by inserting lock washer (#G), then flat washer (#F) onto bolts (#C). Align headboard legs (#5) to the holes of the headboard (#1), then secure with bolts (#C).


STEP 2

Secure top holes of the headboard (#1) and wings (#4) together with bolts (#C) that contains lock washer (#G) and flat washer (#F).


#Bx 4pcs
#Cx 4pcs
#D x 2pcs
#F x 6 pcs
#Gx 10pcs
#E x 4pcs

Align HB leg support (#10) in-between HB legs (#5), then secure with bolts (#B) that contains lock washer (#G) and flat washer (#E).

Secure bottom holes of the HB legs (#5) and wings (#4) together with bolts (#D) that contains lock washer (#G) and flat washer (#F).




Attach footboard legs (#6) onto the footboard (#2).



STEP 3

Align side rails (#3) to the holes of the headboard (#1) and footboard (#2), then secure bolts (#B) that contains lock washer (#G) and flat washer (#E).


#B x 8pcs
#E x 8pcs
#G x 8pcs



STEP 4

Prepare 8 bolts assembly by inserting lock washer (#G), then flat washer (#E) onto bolts (#C). Align support legs (#9) to the holes of the support rails (#8), then secure with bolts (#C) and hex nut (#H).

#C x 12pcs
#E x 12pcs
#G x 12pcs
#H x 12pcs




STEP 5


Prepare 8 bolts assembly by inserting lock washer (#G), then flat washer (#E) onto bolts (#B,C). Align support rails (#8) to the holes of the footboard (#2) and headboard leg support (#10).

#B x 4pcs
#C x 4pcs
#E x 8pcs
#G x 8pcs
#H x 4pcs

Secure support rails (#8) to the headboard leg support (#10) with bolts (#C).



STEP 6



RETURN / DAMAGE CLAIM INSTRUCTIONS

1. **DO NOT** discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch:	sales@tsbliving.co.nz
Christchurch Branch:	customersupport@tsbliving.co.nz
Wellington Branch:	wellington@tsbliving.co.nz