













Assembly Instructions

Model: SC 8004-C


Part List		QTY
1	Top Panel	1
2	Left Side Panel	1
3	Right Side Panel	1
4	Shelves Panel	4
5	Middle Panel	1
6	Bottom Panel	1
7	Leg Panel	1
8	Left Door Panel	1
9	Right Door Panel	1
10	Back Panel	1

Hardware		QTY
A	Dowel 	16
B	CSK Screw M3.5x12mm 	24
C	CSK Screw M4x50mm 	14
D	Hinges 	4
E	Nail 	41
F	Handle 	2
G	Handle Screw 	4
H	Shelf Support 	16
I	White Nail 	5


*Please use screwdriver when assemble CSK screw. 




Step 1




Step 2




Step 3




Step 4




Step 5




Step 6




Step 7




Step 8



Step 9




Step 10




Front View

DOOR TROUBLESHOOTING



Front View


DOOR TROUBLESHOOTING






Front View

DOOR TROUBLESHOOTING

Side View



Front to Front Adjustment




Anti -
Tipping

(A)



CSK Screw
M3.5x16mm
1PC

(B)



CSK Screw
M4x50mm
1PC

(C)





L BRACKET
2PCS



(D)






CABLE TIE
1PC





BACK VIEW



WALL



WALL



RETURN / DAMAGE CLAIM INSTRUCTIONS

1. DO NOT discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: sales@tsbliving.co.nz

Christchurch Branch: customersupport@tsbliving.co.nz

Wellington Branch: wellington@tsbliving.co.nz