



Assembly Instructions

Model: SC 8005-B


Part List		QTY
1	Top Panel	1
2	Left Side Panel	1
3	Right Side Panel	1
4	Middle Panel	1
5	Bottom Panel	1
6	Support Back (R)	1
7	Support Back (L)	1
8	Shelf (L)	2
9	Shelf (R)	2
10	Door Panel (L)	1
11	Door Panel (R)	2
12	Back Panel	1

Hardware		QTY
A	Dowel 	20
B	CSK Screw M4x50mm 	6
C	Mini Fix Bolt 	6
D	Mini Fix Housing 	6
E	CSK Screw M3.5x16mm 	3
F	Panhead M4x25mm,Black 	6
G	Magnet Plate 	3
H	Magnet 	3
I	Door Support 	6
J	Wall Plug 	2
K	Wall Screw 	2
L	Handle 	3
M	Metal Shelf Support 	16
N	Nail 	30


*Please use screwdriver when assemble
CSK screw.Screwdriver (not provided)




Step 1




Step 2




Step 3




Step 4




Step 5



Step 6




Step 7




Step 8


This is how a mini fix works...




The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.




Step 9




Step 10




Step 11




Step 12



Step 13




Step 14




*Use power tool to make
hole at wall (not provided)






Step 15




Step 16



Anti - Tipping	(A)  CSK Screw M3.5x16mm 1PC	(B)  CSK Screw M4x50mm 1PC	(C)  L BRACKET 2PCS	(D)  CABLE TIE 1PC		
---------------------------	---	---	--	---	--	---

BACK VIEW



RETURN / DAMAGE CLAIM INSTRUCTIONS

1. DO NOT discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: sales@tsbliving.co.nz

Christchurch Branch: customersupport@tsbliving.co.nz

Wellington Branch: wellington@tsbliving.co.nz