
















Assembly Instructions

Model: SC 8006-C


Part List		QTY
1	Top Panel	1
2	Left Side Panel	1
3	Right Side Panel	1
4	Center Panel (L)	1
5	Center Panel (R)	1
6	Bottom Panel	1
7	Big Middle Panel (L)	1
8	Small Middle Panel (R)	1
9	Shelf (Big)	2
10	Shelf (Small)	3
11	Shelf (Middle)	2
12	Door Panel (L)	1
13	Door Panel (R)	2
14	Back Panel	2
15	Left Back Panel	1

Hardware		QTY
A	Dowel 	22
B	CSK Screw M4x50mm 	14
C	Mini Fix Bolt 	8
D	Mini Fix Housing 	8
E	CSK Screw M3.5x16mm 	3
F	Panhead M4x25mm 	6
G	Magnet Plate 	3
H	Magnet 	3
I	Door Support 	6
J	White Nail 	6
K	Handle 	3
L	Metal Shelf Support 	28
M	Nail 	46


*Please use screwdriver when assemble
CSK screw.Screwdriver (not provided)




Step 1




Step 2




Step 3




Step 4




Step 5




Step 6




Step 7



Step 8




Step 9




Step 10


Back View




Step 11




Step 12






Step 13



Step 14



Step 15




Anti -
Tipping

(A)



CSK Screw
M3.5x16mm
1PC

(B)



CSK Screw
M4x50mm
1PC



(C)









L BRACKET
2PCS



CABLE TIE
1PC



BACK VIEW



RETURN / DAMAGE CLAIM INSTRUCTIONS

1. DO NOT discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2. Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3. Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch: sales@tsbliving.co.nz

Christchurch Branch: customersupport@tsbliving.co.nz

Wellington Branch: wellington@tsbliving.co.nz