



USER MANUAL

Please read the instructions carefully before assembly and use and keep it for future reference.



INTRODUCTION




Before you begin to use the trampoline, please read all information and instructions in this user manual. Just like any other type of physical recreational activity, participants can get injured. To reduce the risk of injury, please follow the appropriate safety rules and tips.

ATTENTION




- Misuse and abuse of this trampoline is dangerous and can cause serious injury.
- Trampolines are rebounding devices which can propel the performer to unaccustomed heights through a variety of movements. Always use caution when playing on a trampoline.
- Always inspect the trampoline before each use.
- Proper assembly, care and maintenance of the product, safety tips, warnings and proper techniques in jumping and bouncing are all included in this user manual. All users and supervisors must read and familiarise themselves with these instructions. Anyone who chooses to use this trampoline must be aware of their own limitations with regards to performing various jumps and bounces with this trampoline.

Initially, you should get accustomed to the feel and bounce of the trampoline. The focus must be your body position and you should practice each fundamental bounce until you can do each skill with bounce before moving on to more difficult and advanced bounces. Do not bounce recklessly on the trampoline. Emphasis must be made on good control and mastering of various bounce techniques.









DOS AND DON'TS OF TRAMPOLINE USE



Do not perform somersaults (flips) as this will increase the chance of head or neck landing. It may cause paralysis or even death.



A maximum of one person is allowed on the trampoline! Jumping with multiple people increases the risk of injury due to collision.



TRAMPOLINE GUIDELINES

PURPOSE

- This product is intended for domestic use only and is not suitable for professional or medical use.
- The maximum weight capacity is 150kg. Overloading the trampoline above the recommended weight capacity will cause damage to the trampoline which is not covered by the warranty.

DANGER FOR CHILDREN

- Do not let unsupervised children near this product. Carry out the necessary safety precautions and supervise all trampoline activities.
- Be aware that the packaging material can be dangerous to children because of suffocation hazards.
- Trampoline over 51cm in height are not recommended for children under the age of 6 years old. Such children will not recognise the potential danger from this product. Keep these children away from this product as it is not a toy.
- This product has to be stored out of reach of children and pets.

PRODUCT DAMAGES

- Do not alter the product. Only use original parts. Repairs should be carried out by qualified technicians only. Improper repairs can compromise the safety of the trampoline. Use this product only as described in this manual.
- Protect the product against humidity and high temperatures.

ASSEMBLY ADVICE

- The assembly of this product must be carried out by at least two able-bodied adults. If in any doubt, please consult a technically qualified person for assistance.
- Before commencing assembly, read all the instructions in this user manual.
- Remove all packaging materials and lay down all parts on an open space. This will give you an overview and better facilitate the assembly process.
- Check the contents of the packaging and ensure that there are no missing parts. Dispose of the packaging materials when the assembly is completed.
- Please be aware there will always be a risk of injury when using tools or performing technical work. Hence, assemble the product carefully.
- Create a danger-free environment such as not leaving tools lying around the work space.
- Store the packaging materials in such a way that will not cause any danger. Foils and plastic bags are dangerous for children as they are suffocation hazards.
- After assembling the product, please ensure that all screws, bolts and nuts are correctly installed and tightened, and that all joints are tightly connected.
- A clearance space of at least 7.3m is necessary above the trampoline. An appropriate clearance must be kept between the trampoline and possible sources of danger, such as electrical cables, tree branches, swimming pools and fences.
- The trampoline must be properly set up before use.
- Never set up the trampoline in rainy, windy or stormy conditions and poor lighting conditions. It is recommended that the trampoline be taken apart and stored in bad weather.
- The metal frame of the trampoline will conduct electricity. Lightning, extension cords and all electrical equipment must never be allowed to come in contact with the trampoline.

ASSEMBLY ADVICE

- The trampoline must always be set up in a well-lit area.
- Do not place any object under the trampoline.
- The trampoline must not be used when it is in the vicinity of other leisure devices and construction.
- When assembling or disassembling the trampoline, please use gloves to protect your hands.

ADDITIONAL TIPS

- For additional stability, you can place sand bags on the trampoline legs. This will prevent the trampoline from tipping over in the event of any sideward force.
- Do not use the trampoline during pregnancy.
- Do not use the product if suffering from high blood pressure.
- Jump with bare feet. Do not wear shoes as this will damage the jumping mat and will not be covered by warranty.
- Do not smoke when using the trampoline.
- Do not place cigarettes, sharp objects or any similar objects on the trampoline.
- Do not place pets in the trampoline.
- Do not use the trampoline when under the influence of alcohol or drugs.
- Do not sit or lean on the cover pads as they need to be flexible so that they can move together with the jumping mat. Please do not allow small children to climb onto the trampoline by using the cover pads. Any tear caused by obstructing the cover pads is not covered by the warranty.
- Place the trampoline on a flat and level ground and preferably on grass. Locating the trampoline on hard surfaces will add stress to the frame over time. Such damage is not covered by the warranty.
- Do not place the trampoline on uneven ground as it may tip over when in use.
- Do not expose the trampoline to any direct contact with open flames.
- Secure the trampoline against unauthorised use.
- The trampoline should be tied down with anchors (not provided) during windy conditions or disassembled and stored away.



WARNING •

1. Maximum weight capacity is **150kg**.
2. Adult supervision required.
3. Read the instructions carefully.
4. Always close the net opening before using the product.
5. The net should be replaced every year.
6. For outdoor use only.
7. Ensure that the safety enclosure net zipper is fully closed before trampoline use.
8. Do not intentionally jump into the safety net. The net is only designed to stop persons from falling over the trampoline. Intentional jumping into the net may cause the trampoline to tip over or damage the net. Abuse of the safety net is considered as negligent use and is not covered by the warranty.



WARNING

1. Only one user at a time to avoid any collision hazards.
2. Maintain a minimum clearance of 7.3m above the trampoline from ground level in order to prevent users from inadvertently contacting overhead hazards such as electric wires, tree limbs, clotheslines or ceilings.
3. Do not locate the trampoline on top of other objects or store anything underneath the trampoline bed.
4. The owner and supervisors of the trampoline are responsible to ensure that all users are aware of practices specified in the User Manual.
5. Use the trampoline only with matured and knowledgeable supervision.
6. Do not attach anything to the barrier that is not a manufacturer-approved accessory or part of the enclosure system.
7. Bounce only when the surface of the bed is dry. Wind or air movement should be calm to gentle. The trampoline must not be used in gusty or severe winds.
8. Do not use a trampoline while under the influence of alcohol or drugs.



Keep small children at least 7.5m away while assembling the trampoline.



The maximum user weight for this trampoline is 150kg. Jumpers at or near the maximum user weight should take extra precautions in their manoeuvres to ensure that they do not initiate contact with the ground while jumping as this can cause serious injury.



The trampoline should not be placed on concrete, brick or other hard surfaces or near other conflicting installations such as pools, swings and climbing frames to prevent any serious injuries to users should be fall off the trampoline.



Only use approved Mazam trampoline accessories and install them in accordance to installation instructions.



Adult supervision required at all times. Users must be 2 years and above.



If you anticipate severe weather, consider lowering the enclosure, moving the trampoline to a sheltered location or disassembling completely.



Do not attempt to use the trampoline until it is completely assembled.














Do not make modifications to the trampoline or accessories.

SAFETY INSTRUCTIONS


- All users of the trampoline needs to supervised regardless of age and experience of the user.
- The safety instructions of the trampoline must be strictly obeyed and considered.
- Somersaults must be avoided. Incorrect landings on the trampoline can lead to injuries, particularly to the back, neck or head. Injury may cause paralysis or even death.
- Only one person shall use the trampoline at a time. Multiple users on the trampoline will increase the risk of collision.
- The trampoline must be examined for damage, wear and tear or defective parts before each usage as it may impair the overall safety of the trampoline. Damage, worn or defective parts must be replaced immediately before it can use. In the meantime, the trampoline must be restricted from access.
- No clothes with hooks should be worn when using the trampoline to prevent any clothes entanglement.
- The trampoline must be set up only on a flat and even ground and on non-slippery surfaces.
- Strong winds can blow the trampoline away. If strong winds are predicted, the trampoline must be moved to a protected location or disassembled. If not, the trampoline needs to be secured to the ground with anchors and cords (not provided). At least three anchorages are necessary. It is not enough to anchor the pennants to the ground as they can tear away from the patch cords.
- Try to avoid moving the trampoline after it is assembled as it could bend during transportation. If it is necessary to move the trampoline, please consider having four persons to be evenly spaced around the trampoline frame and lift the trampoline off the ground. The trampoline must be moved horizontally and if needed, shift the trampoline back into shape with the help of the four persons.
- Trampolines are jumping devices that enable the user to jump to unusual heights as well as into various body movements. Please be aware that jumping into the trampoline, hitting the frame or cover pads or incorrect landing on the trampoline can lead to injuries.
- Users should be familiar with the user manual instructions. This manual contains assembly instructions and selected precautionary measures and recommendations for servicing and maintenance of the trampoline in order to ensure a secured and fun use of the trampoline.
- It is the responsibility of the owner or the supervisor to ensure that all users of the trampoline are informed of sufficient space around it as a safety precaution.
- Never use the trampoline near any water body.
- Beware of moving parts of the trampoline which can capture a user's arms and legs.
- Do not stick foreign objects into the trampoline.
- Do not allow anyone or any object to go under the trampoline while someone is jumping on the trampoline. The moving jumping mat may cause serious injury to that person under it.
- Implement safety rules and familiarise yourself with the information in the user manual.
- The trampoline can only be used when the jumping mat is dry. A worn or damaged jumping mat must be immediately replaced.
- Any object that may pose a danger to the user must be moved away.
- Avoid unauthorised or unsupervised use of the trampoline.
- Do not use the trampoline when under the influence of alcohol or drugs (including medication).
- Learn the fundamental techniques of jumping thoroughly before attempting difficult jumps.
- Climb onto the trampoline instead of jumping directly into it. Do not use the trampoline as a jump board for other devices.
- If required, seek a trained trampoline teacher for more exercise options.

Hardware List

Please ensure that all parts and hardware are in the packaging contents. If there are any missing parts and/or hardware, please contact our Customer Service as soon as possible.

Part A 2pcs Rectangle Frame - Left 	Part B 2pcs Rectangle Frame - Right 	Part C 2pcs Frame Tube - Long 	Part D 2pcs Frame Tube - Short 	
Part E 4pcs Bent Leg 	Part F 2pcs Leg Tube 	Part G 8pcs 6x12mm 	Part H 38pcs Spring 	
Part I 1pc Spring Tool 	Part J 1pc Spring Cover + Jumping Mat 	Part K 4pcs Safety Net Pole 	Part L 1pc Safety Net 	
Part M 2pcs Top Arc Pole with Ring 	Part N 2pcs Top Arc Pole 	Part O 2pcs Upper Safety Net Pole 	Part P 4pcs 6x35mm 	
Part Q 1pc Swing 	Part R 1pc Horizontal Pole 	Part S 1pc Allen key 	Part T 1pc Screwdriver 	Part U 4pcs 4.8x16mm 


Parts List



STEP 1


Part A

2pcs




Part B

2pcs





Part C

2pcs





Part D

2pcs




1. Connect the Frame Tubes (A, B, C and D) to form a rectangle. Ensure that the holes of the Frame Tubes are facing upwards.
2. Note the positions of the Frame Tubes A and B that have longer and shorter ends when connecting the Frame Tubes together.

Tip: After the Frame is assembled, please check that the overall shape is properly aligned and not out of shape. Adjust accordingly if necessary.




STEP 2

Part E
4pcs




Part F
2pcs



Part G
4pcs




Part S
1pc



1. Attach the Bent Legs (E) to the Leg Tubes (F) as shown.
2. Secure the connections with Screws (G) using the Hexagonal Wrench (S).

STEP 3



1. Lift the Frame and carefully insert it into the Bent Legs (E). This is the underside of the Frame.
2. Once done, turn the Frame over and let it stand on the Bent Legs.


STEP 4

Using the Spring (H), attach the larger hook (a) to the Frame and the smaller hook (b) to the D-ring of the Jumping Mat.





Part H
38pcs







Part I
1pc



Part J
1pc




To facilitate an easier attachment of the Spring (H), use the Spring Tool (I) to help attach the large hook to the Frame as shown.



1. Start with attaching two Springs (H) to the four corners of the Frame.
2. Next, attach two Springs (H) to the centre of the Frame as shown and then work diagonally across the Frame with the rest of the Springs (H).

STEP 5




1. Lay the Spring Cover (J) over the Frame to cover all the Springs (H). Next, tie the webbing straps to the underside of the Frame.
2. Continue with the process until the Spring Cover is securely fastened to the Frame.

STEP 6


Part K

4pcs



Part T

1pc




Part U

4pcs
4.8x16mm



Part G



4pcs



STEP 7

Part L

1pc



1. When installing the Safety Net (L), ensure that its blue pad is at the bottom.
2. Ensure that the Safety Net (J) is installed outside the four Safety Net Poles (K) with its blue pad at the bottom. The zipper of the Safety Net (J) acts as an entrance to the trampoline.
3. Pull the Safety Net all the way down on all four sides.

STEP 8

Part M

2pcs




Part N

2pcs



Step 1


Connect the Top Arc Poles (M and N) as shown.



Step 2


Insert the connected Top Arc Poles into the sleeves of the Safety Net.

TIP: Ensure that the Swing rings of the Top Arc Poles are in the same position during the installation.



Step 3


Insert both ends of the Top Arc Poles into the upper part of the Safety Net Poles (K) as shown.



STEP 9

Part O

2pcs




Part P

4pcs



Part S

1pc



1. Insert the Upper Safety Net Pole (O) into the sleeves of the Safety Net as shown.
2. Align the screw holes at both ends of the Upper Safety Net Poles (O) with the screw holes of the Safety Net Poles (K). Then secure the assembly with Screws (P) using the Hexagonal Wrench (S).
3. Attach the hook fasteners to the Safety Net Poles.
4. Finally, hang the plastic hooks of the Safety Net onto the D-rings of the Jumping Mat.

STEP 10



Part Q

1pc



Part R

1pc



1 Swing Installation

Attach the spring snap hooks of the Swing (Q) to the rings of the Top Arc Poles as shown.



2 Horizontal Bar Installation

Attach the spring snap hooks of the Horizontal Pole (R) to the rings of the Top Arc Poles as shown.



ATTENTION :

The Swing (Q) and Horizontal Pole (R) cannot be used together. Select one item to install.

Thank you for choosing our products.

Should you have any questions during use, please feel free to contact us anytime.

We wish you a wonderful experience with our items.