





Assembly Instructions


Model: MPC 8053-B

Part List		QTY
1	Top Panel	1
2	Left Side Panel	1
3	Right Side Panel	1
4	Center Panel	1
5	Bottom Panel	1
6	Left Shelf Panel	1
7	Right Shelf Panel	1
8	Leg	1
9	Back Panel	1
10	Door 1	1
11	Door 2	1
12	Door 3	1
13	Door 4	1


Hardware List		QTY
A	Plastic Dowel 	22
B	Mini Fix Bolt 	8
C	Mini Fix Housing 	8
D	CSK Screw M3.5x12mm 	32
E	CSK Screw M4x50mm 	14
F	Door Support 	8
G	Magnet Plate 	8
H	Magnet 	8
I	White Nail 	5
J	Nail 	44
K	L Bracket 	2




Step 1




Step 2



Step 3




Step 4




Step 5

Back View



Step 6

Back View





Step 7

Back View

This is how a mini fix works...


The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.






Step 8

Back View




Step 9

Back View




Step 10


Back View




Step 11




Back View




Step 12





This is how a mini fix works...



The head of the mini fix housing goes into the open mouth of the mini fix bolt. You then turn the mini fix housing so it tightens over the mini fix bolt.



Step 13




Anti -
Tipping

(A)



CSK Screw
M3.5x16mm
1PC

(B)



CSK Screw
M4x50mm
1PC

(C)





L BRACKET
2PCS




(D)






CABLE TIE
1PC





BACK VIEW



WALL



WALL



RETURN / DAMAGE CLAIM INSTRUCTIONS

1.DO NOT discard of the box / original packaging.

In case a return is required, the item must be returned in original box. Without this your return will not be accepted.

2.Take a photo of the box markings.

A photo of the markings (text) on the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.

3.Take a photo / Video of Damage (if applicable).

A photo /Video of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.

4. Send us an email with the images requested.

Email us directly with the attached images, order number (SOXXXX) and a description of your claim.

Auckland / Waikato / BOP Branch:	sales@tsbliving.co.nz
Christchurch Branch:	customersupport@tsbliving.co.nz
Wellington Branch:	wellington@tsbliving.co.nz